



All dimensions shown are in millimetres

Construction: **Glass front panel**  
Connections: **1.2m long flying lead (2 core)**

| Model         | Height<br>± 2mm | Width<br>± 2mm | Finish | Output<br>Watts | Weight<br>kg |
|---------------|-----------------|----------------|--------|-----------------|--------------|
| FZW-150-042/F | 1476            | 435            | white  | 500             | 13.3         |
| FZB-150-042/F | 1476            | 435            | black  | 500             | 13.3         |
| FZM-150-042/F | 1476            | 435            | mirror | 500             | 13.3         |
| FZW-150-052/F | 1476            | 535            | white  | 650             | 16.2         |
| FZB-150-052/F | 1476            | 535            | black  | 650             | 16.2         |
| FZM-150-052/F | 1476            | 535            | mirror | 650             | 16.2         |
| FZW-180-042/F | 1796            | 441            | white  | 650             | 17.0         |
| FZB-180-042/F | 1796            | 441            | black  | 650             | 17.0         |
| FZM-180-042/F | 1796            | 441            | mirror | 650             | 17.0         |
| FZW-180-052/F | 1796            | 540            | white  | 800             | 20.0         |
| FZB-180-052/F | 1796            | 540            | black  | 800             | 20.0         |
| FZM-180-052/F | 1796            | 540            | mirror | 800             | 20.0         |

Issue 1.0



## Tools & Material Required

Masonry drill bit  
Screwdriver  
Electric drill  
Spirit level  
Stepladder (for taller radiators)

| Key | Component         | Qty |
|-----|-------------------|-----|
| A   | Wall Plug         | 4   |
| B   | Bracket           | 4   |
| C   | Screw             | 4   |
| D   | Washer            | 4   |
| E   | Coach Bolt        | 4   |
| F   | Sliding Post      | 4   |
| G   | Grub Screw        | 4   |
| H   | Allen Key         | 1   |
| I   | Adjustable Spacer | 1   |

## Assembly Instructions

Accurately mark out four bracket holes on wall using spirit level.

Drill four holes & insert wall plugs (A).

Attach brackets (B) to wall with screws (C) & washers (D).

Screw coach bolts (E) into sliding posts (F).

Fix sliding posts (F) to mounting plates on rear of radiator.

*It is recommended to secure the radiator only with the coach screws (E) on the upper mounting plates. Leave the lower coach bolts (E) slightly loose to allow the expansion of the radiator when heating.*

Hang radiator by inserting sliding posts (F) into brackets (B).

Tighten grub screws (G) with Allen key (H).

Extend adjustable spacer (I) until it is just touching the wall and lock in place with nut.

Electric radiators should be fitted only by a qualified electrician and must be earthed and connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '5 amp fused fixed spur' located outside the bathroom.

*Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.*

